

TAYLOR STUDIOS Box 847 Kingshill, St. Croix, VI 00851-0847
Phone: 340-718-1364 website: taylorstudiosvi.com
An Eligible Supplier to the EDC Companies

These handmade thin Danish pattern soaps (brick) vary slightly in color. Open all of the crates and use from them at random so the color variations will be well mixed. This makes a good antique look.

Handmade brick vary in size also. These are about 4 1/4" x 8 1/2" or 9". Always make the space of one brick including the end and side joint be 4 3/4" x 9" or 9 1/2" letting the joint be larger or smaller as necessary.

To install the soaps, we recommend a mortar mix of one part gray Portland cement and four parts fine sand wetted with half water and half Acryl 60 (or Acrylbond). This makes a strong waterproof bond. Wet the back of the soaps and the slab a little if necessary. Clean mortar from the top of the brick with a wet sponge as you go. **Don't let it dry on the surface of the brick.**

Before grouting the joints, seal the installed brick surface by rolling on a coat of clear silicone sealer (we recommend Water Ban 90) or at least some Thompsons' Water Seal. This can be done a short time before grouting, (half hour), will give the best look, and save a great deal of time and labor.

Make the grout from one part white cement, four parts fine sifted sand, a small amount of yellow cement coloring, (about one ounce for a five gallon bucket of mix), and some water. Don't make it too thin. Put the thick grout mixture into the joints with the edge of your trowel, packing it in and leveling as you go. Follow up in a short time with rodding tool. We use one made from a 1/2" PVC pipe. Clean any smears from the brick with a damp sponge.

The vehicular brick and regular Danish pattern brick can be laid without pouring a slab.

Prepare the ground by enclosing the patio area with 6" blocks. These blocks may need rebar driven into the cells for stability. Thoroughly tamp the dirt within the area and top with 1/4" minus stone to within 2" of the bottom of

TAYLOR STUDIOS Box 847 Kingshill, St. Croix, VI 00851-0847
Phone: 340-718-1364 website: taylorstudiosvi.com
An Eligible Supplier to the EDC Companies

the tile. Fill the rest of the underlayment with a mixture of dry sand and cement (20% cement). Screed this topping level. Stretch strings to align one edge of the tile. Place the tile or brick on top of the dry sand and cement. When all the tile or brick have been placed, soak the area thoroughly with water and stay off the tile for a couple of days. Seal the dry tile or brick with Water Ban 90, or a good siloxane penetrating sealer. Grout the seams with a grout colored the same as the tile. Seal the entire patio once again thoroughly, and re-seal as necessary.

See our website for pictures of this installation procedure:
www.taylorstudiosvi.com.

If you follow these instructions you will be very pleased with the results.
Call us if you have any questions. We will be glad to help.

**PLEASE DO NOT ACID WASH OR PRESSURE
WASH THESE COLORED CONCRETE PRODUCTS.**